

TTPRO Creo 3.0 Video Training Courses

Assembly Drawings:

1. Front views
2. Back Views
3. Top Views
4. Right View
5. 3D views
video clips: **Assy_Orientation**
6. Explode view and position component and options
video clips: **Assy_explode**
7. section view.
video clips: **Assy_sec**
8. Assembly Drawings,
9. General view
10. Parent view,
11. Project view
12. Detail view
13. Auxiliary view
14. 3D view
15. how to break relationship of each view.
16. View Alignment;
17. View display mode and other functions related.
video clips: **Assy_dwg_views**
18. Assembly Explode View set up
19. Position components in for the explode view.
video clips: **Assy_dwg_explode**
20. Assembly Section View set up
21. Section view reference arrow,
22. Full Section View
23. Partial section View
24. Exclude parts from section view.
25. Made section view in drawing if model has not been set up sections.
video clips: **Assy_dwg_sec**
26. Make Breaking View
27. Set up breaking view
28. Breaking View options.
video clips: **Assy_dwg_brk_view**
29. Insert multi models.
30. Del model;
31. set model;
32. Remove model.
33. Model display.

Video clips: **Assy_dwg_model_setting**

- 34. BOM table
- 35. BOM bubble

Video clips: **dwg_BOM_tbl**

- 36. Assembly Drawings,
- 37. Review tab Introduce functions and options in this tab.

Video clips: **Assy_dwg_review**

- 38. Add Table
- 39. Add call out.
- 40. Add notes and flag notes.
- 41. Add Rev. symbol.
- 42. Add BOM bubble to the drawing

Video clips: **Assy_dwg_annotation**

- 43. Tolerance
- 44. GD&T
- 45. GD&T setting table.

Video clips: **dwg_GDnT**

- 46. Save drawing as PDF,
- 47. Save drawing inter-exchange file.
- 48. Plot setting.

Video clips: **Assy_dwg_save_and_prnt**

